



SimWalk User Guide

COPYRIGHT

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without prior written permission of Savannah Simulations AG.

The information in this publication is provided for information only and is subject to change without notice. Savannah Simulations AG and its affiliates assume no responsibility or liability for any loss or damage that may arise from the use of any information in this publication. The software described in this document is furnished under License and may only be used or copied in accordance with the terms of that License.

ABSTRACT


This Quick Start Guide shows in a short overview how to run the demo projects included in SimWalk Demo and how to view and analyse the simulation results.

This Quick Start Guide is intended to lead the user quickly into the main functionalities and possibilities of SimWalk Pedestrian Simulation. For more detailed information see the SimWalk User Guide.


Note: If you first want to get an overview of the simulation data in the demo project and see the powerful features of SimWalk you can go to chapter 2 and view the demo movie.

1. Run the demo project

- 1 After a successful setup, start SimWalk main program by double-clicking the desktop icon or selecting Start/Programs/SimWalk 4.0.




- 2 The main window opens and the program copyright and version info are shown.




3 The Display window opens, showing the architectural drawing. On the right side, the Legend panel displays two levels, 'Concourse' and 'Station' and additional information regarding the architecture (drawing name, width, height, and number of levels).


Hint: If you don't like the small blue icons (introduced in version 4.0), just rename the 'Icons' directory in the SimWalk data folder (e.g. 'Icons_off').



- 4 Press the [Info] button to get more information about the active level.




- 5 In the 'Select a task' menu choose the task 'Run a new simulation'.




Note: Some items may be disabled depending on the features of your license.

6 The Display and Simulation windows open.



7 In the 'Select a mode' menu of the Display, choose 'Display mode'.




8 Press the [Start] button to run the simulation.



9 SimWalk starts the simulation process. After creating the levels, objects, and agents and building the potential fields, Simulation and Display windows allow choosing different display modes and levels on two independent screens.

Tip: If you have a dual-head video card and a second monitor, you may draw the Simulation window on the second monitor (if enabled in the Options).




A Main tool bar B Display tool bar C Display legend panel D Display status bar E Messages window F Status window G Main status bar	<ul style="list-style-type: none"> - Select and control the simulation - Select and control the presentation - Show and control the visual elements - Provide information about the layout - Show information, warnings, and error messages - Provide information about the agents status - Provide information about the simulation run
---	---


A1 Use the control buttons to [Pause], [Step], [Continue], [Stop], or [Skip] the simulation run.




A2 Selecting [Settings] drop-down button, you can show or hide information panels and auxiliary windows.




A3 You may consider tracking system and simulation information like processor load, memory usage, and process and security status.



A4 Press the [Hazard control] button to get an overview of all manual and time controlled hazards currently defined in the project.




B1 Change the Display mode as you like.




Hint: Some items may be disabled depending on the settings in the Configuration.

B2 Select 'Max density' or 'Mean density' mode to show a density map (P/m^2 , m^2/P , P/yd^2 , or ft^2/P) according to Configuration settings. Pay attention to density cell information, displayed in the Legend panel, regarding the color scheme in use. In the figure below the cell color corresponds to the current density in agents per square meter.




Select any density cell with a left mouse button click to show the density cell properties.

B3 Select 'Spatial utilisation' mode to show a load map according to Configuration settings. Pay attention to the load cell information, displayed in the Legend panel, regarding the color scheme in use. Select any load cell with the left mouse button and click to show the load cell properties.




Select any load cell with a left mouse button click to show the load cell properties.

B4 Select 'Speed loss' mode to show a speed map according to Configuration settings. Pay attention to the speed loss information, displayed in the Legend panel, regarding the color scheme in use. In the figure below the cell color corresponds to the percental speed loss in relation to the desired agents walking speed.



Select any speed cell with a left mouse button click to show the speed cell properties.


B5 Select 'Agents trails' mode to show a trajectory map according to Configuration settings. Pay attention to the trail information, displayed in the Legend panel, regarding the color scheme in use. In the figure below the trail color corresponds to the last waypoint (Exit).



Select any trail with a left mouse button click to show the agent properties. The current position of the agent is marked by a small yellow hair cross while the properties are updated in the info window.

Tip: See appendix D for the meaning of agent status.

B6 Select 'Agents flow' mode to show an agents map according to Configuration settings. Pay attention to agent information, displayed in the Legend panel, for the color scheme in use. In the figure below the agent color corresponds to the current walking speed.




Select any agent or vehicle with a left mouse button click to show the agent or vehicle properties, respectively. The current position of the agent or vehicle is marked by a small yellow hair cross while the properties are updated in the info window.

Tip: Select the menu item 'Locate position...' or double-click somewhere into the Display to locate either a point by its X/Y-coordinates or an agent by its number.

Tip: See appendix D and E for the meaning of agent and vehicle status.

B7 Display tool bar also allows changing the active level. The selected level will be shown and activated. Only the active level allows selecting agents, trails, cells, vehicles and other objects.



B8 Use tool buttons to [Zoom] or [Fit] the drawing or change the view to [Isometric] or [Perspective]. Use [+/-] spin buttons to set the drawing zoom (in %) and the viewing angle (in °) as desired.


Tip: Double-click into the zoom or angle indicator will restore the last value.

Note: The zoom will be adjusted automatically to fit the drawing (if enabled in the Options).


In the figure below agent symbols (some accessory equipped) with an isometric view of 30° to both levels are shown.




B9 Use tool buttons to [Zoom to area] of interest by dragging the left mouse button to see more details,




or [Measure distance] within the drawing using the tapeline tool.




B10 Alternatively, use $[+/-]$ spin buttons to zoom in or out the drawing by steps of 10%. The current zoom factor is shown as a percentage in relation to the drawing dimensions.




B11 Click with the right mouse button into the drawing or the zoom indicator to pop-up a menu with zoom, printer, locator, and options items.



B12 Press [Rulers], [Grid], [Background], [Images], [Timeline], and [Legend] buttons to show or hide the corresponding visual elements. Show or hide line and area counter(s) in the counter drop-down menu by selecting the appertaining checkboxes.




B13 Use [Chart] button to show or hide the counter chart. Use left mouse button to move or resize the chart, and the right mouse button to open the pop-up menu for various settings relevant for presentation and counter allocation.



B14 Use [Timer] button to display run pass number and time of simulation run.



B15 Use left mouse button to move or resize the timer and the right mouse button to open the pop-up menu for various settings relevant for presentation.




B16 Press [Display text] button to enter optional remarks indicated in pictures or movies. Use left mouse button to move or resize the text label, and the right mouse button to open the pop-up menu for various settings relevant for presentation.




B17 Use tool buttons to [Make snapshot] or [Record video] of the simulation display. The pictures are saved in the preselected graphic format in the simulation run folder of the project and can be viewed later or used to make a movie (see chapter 2.21).

Note: Select GIF video format to make movie using the SimWalk Movie Maker and PNG to make true color AVI/MPEG movies (needs free 3rd-party video utilities).


Remark: The [Record video] button is only available in the Simulation display.



B18 Press [Print] button to make a hardcopy of the currently seen display.



B19 Right-click into the drawing or the zoom indicator to select and setup the desired printer.




C1 The color scheme is shown according to Display mode and Configuration settings for:

- Agents speed (m/s or ft/s)
- Speed loss (%)
- Spatial utilisation (Agents rel. to load reference)
- Density (P/m² or P/yd²)
- Space (m²/P or ft²/P).


m/s	Color	%	Color	Agents	Color	P/m ²	Color
> 0.00	Red	> 0	Purple	> 0	Blue	< 0.42	Light Blue
> 0.50	Orange	> 15	Cyan	> 50	Dark Blue	< 0.89	Cyan
> 1.00	Green	> 30	Light Green	> 100	Dark Purple	< 1.35	Light Green
> 1.50	Dark Green	> 45	Yellow	> 150	Maroon	< 1.72	Yellow
> 2.00	Cyan	> 60	Orange	> 200	Dark Red	< 2.00	Orange
> 2.50	Blue	> 75	Red	> 250	Red	> 2.00	Red

C2 Show or hide levels, objects, and agent groups by clicking the appertaining checkboxes shown in the Display's Legend panel on the right side. The Legend panel can be set on or off in the Settings drop-down menu or by pressing the [Close legend] button.




D1 In the Display status bar, the current level number, drawing dimensions and unit (m or yd), cursor position, project and level name are shown. The timeline on top is a graphical representation of the runtime and the estimated duration. The timeline can be set on or off in the Settings drop-down menu or by pressing the [Close timeline] button. During a simulation, the timeline pointer indicates the current runtime whereas the scale marking is adjusted according to the estimated end of the simulation. If Formations are defined, they

are shown as orange boxes marking the arrival and departure times (SimWalk Transport and Airport only). Small circles indicate Hazard events (if defined).



E1 In the Messages window, general information, warnings, status and error messages are shown. This window can be set on or off in the Settings drop-down menu or by pressing the [Close messages] button.

Tip: If an error message contains either an X/Y-coordinate or an agent number, you can double-click the appropriate line to locate that point in the Display.



F1 In the Status window all pending, active, moved, waiting, or done agents as well as agent groups with the same waypoint and their average speed (m/s or ft/s) are shown. Right-click into the table to pop-up a menu with aligning, clipboard, export, and table settings items. This window can be set on or off in the Settings drop-down menu or by pressing the [Close status] button.

Status


Exit	Pending	Active	Moved	Waiting	m/s	Done
Total	894	167	67	24	0.98	0
1	894	31	0	1	0.00	0
2	0	6				0
3	0	10				0
4	0	52				0
5	0	22				0
6	0	2				0
7	0	9				0

Agents: 1061 | Waypoints: 25 | Pass 1: 08:00:53.50

G1 In the main Status bar, actual date and time, real time, run pass and time, progress in % agents done, run pass name and currently used agents plan are shown.



10 After the simulation has terminated, the Completion dialog appears where you may fill in various information about the simulation run. Rename the simulation run to 'Test Run 2' and enter an optional project description, then press [Save] button to save it in the project folder. Press [Discard] if you don't want to save the simulation data.




11 If the checkbox 'Show simulation report' is set, a simulation summary is shown in the SimWalk Document Reader.

SimWalk Simulation Report			
	22.03.2012	11:03	Vers. 4.0
Project Information			
Project name:	Demo_Airport	Project run:	Test Run 2
Organisation:	Savannah Simulations AG	Operator:	KEN
Agents plan:	plan_00.swt	Objects library:	SimWalk.swo
Project drawing:	Airport.swd	Drawing levels:	2
Drawing width:	120.0 m	Drawing height:	80.0 m
Description:	Test Run for User Manual		
Configuration Settings			
Potential cell size:	25 cm	Time step:	0.50 s
Measuring cell size:	160 cm	Way finding:	3
Object range:	20 cm	Pressure factor:	1.00
Interaction range:	170 cm	Log interval:	10 steps
Temperature:	15 °C	Unblock agents:	200 steps
Load reference:	250 agents	Level of service:	User defined
Simulation Summary			
Start time:	16:02:55	Total agents:	1061
End time:	16:13:31	Total waypoints:	25
Real time:	00:10:35.00	Run passes:	1
Run time:	00:16:18	Run steps:	1958
SimWalk Report	ANSI 1252	Lines: 129	9.8 kB
			C:\ProgramData\SimWalk 4.0\Projects\Demo_Airport\TestRun01\

2. View the simulation results


1 After having saved a simulation run, collected data can be viewed and analysed. In the 'Select a task' menu choose task 'View simulation results'.



2 In the 'Select a run' menu...




...choose the run 'TestRun01'.




3 In the 'Select a file' menu...




...choose the file 'DemoMovie'.



4 The SimWalk Viewer opens and the movie is loading and then playing. Use the control buttons to [Pause], [Next], [Stop] and [Play] the movie. Use the [Zoom] and [Speed] buttons to change the presentation.



5 Repeat step 3 and choose file 'Density map'.




6 In the 'Select a pass' menu choose the pass 'Run pass 1'.




7 The density map opens in the Display window. You may select actual, maximum, or mean density mode, enter a time range and then press the [Density map] button to refresh the density map.

Hint: The data processing may take several seconds before the density map is updated.



8 Repeat step 3 and choose the file 'Database'.



9 The SimWalk Data Analyser opens and shows the configuration table. Select any mode and table of your interest.

Tip: See appendix D and E for the meaning of agent and vehicle status.

AgentId	StartTime	Start	End	ExitPoint	AgentType	Profile	Priority	Breadth	Height	Age	Gender	Speed	Steps	Distance	Duration	MaxSpeed	AvgSpeed
0	42300	1		0	Agents statistic		0	40	170	81	1	50	268	8600	13400	96	64
1	1100	1		0	Agents counters		0	38	173	28	1	134	173	7988	9650	134	92
2	26500	1		0	Agents flow rates		0	38	182	73	1	103	303	8640	15180	103	59
3	19500	1	2	32150	1		0	41	168	37	1	122	253	8487	12650	122	67
4	5400	1	2	13300	1		0	46	180	43	0	159	159	8583	2900	159	309
5	14000	1	2	46350	1		0	35	174	35	1	138	297	9137	14350	138	64
6	3400	1	2	15150	1		0	37	174	54	1	123	295	8261	9790	123	85
7	12500	1	2	23650	1		0	37	168	40	1	140	223	8482	11150	140	76
8	57900	1	2	36700	1		0	40	168	29	0	93	376	9024	18800	93	48
9	47700	1	2	61650	1		0	46	181	32	0	193	279	9290	13950	193	67
10	31590	1	2	45650	1		0	47	175	44	1	134	283	8664	14130	134	61
11	41600	1	2	50800	1		0	37	168	43	1	140	194	8117	9200	140	88
12	66400	1	2	61650	1		0	37	170	43	1	183	293	9470	14650	183	65
13	23400	1	2	36750	1		0	35	173	37	1	133	267	8867	12350	133	67
14	49000	1	2	56150	1		0	41	157	37	1	133	267	8867	12350	133	67
15	34600	1	2	46500	1		0	44	190	55	0	160	223	8951	11150	160	80
16	9800	1	2	17950	1		0	57	192	22	0	226	238	8951	13900	226	75
17	12500	1	2	23800	1		0	42	167	43	1	152	228	8956	11400	152	79
18	55790	1	2	73200	1		0	37	167	49	1	119	270	8795	13900	119	65
19	20500	1	2	34950	1		0	51	179	28	0	138	277	9120	13850	138	66
20	27300	1	2	46250	1		0	46	177	56	0	120	253	8838	12650	120	30
21	46300	1	2	58750	1		0	46	167	37	1	134	249	8677	12450	134	70
22	38300	1	2	50450	1		0	43	171	17	1	151	243	8981	12130	151	72

10 Open Options drop-down menu and select item 'Export table' to save the database table as an Excel or text file. You also may select other items for various settings and data manipulations. In the mode 'Database tables', you can open the 'Select table' menu to choose the item 'SQL query'. This enables you to perform a predefined or self-defined SQL query on the database table(s).

SimData Vers. 4.0 - Copyright by Savannah Simulations AG - Trial Version

Database tables Agent_1

AgentId StartTime StartLevel StartPoint ExitTime ExitLevel ExitPoint AgentType Profile

Gender Speed Steps Distance Duration MaxSpeed AvgSpeed

0 12300 1 2 19750 1 0 0 138479193 8 1 90 268 8600 13400 96 64

1 11300 1 2 40850 1 0 0 536673003 8 1 134 173 7968 8650 134 92

2 26500 1 2 40850 1 0 0 67308864 8 1 103 303 8640 15150 103 59

3 19500 1 2 32150 1 0 0 67308864 8 1 122 253 8467 12550 122 67

4 5400 1 2 13300 1 0 0 67308864 8 0 159 159 8583 7900 159 309

5 14000 1 2 46350 1 0 0 517002944 8 1 138 297 9137 14150 138 64

6 5400 1 2 15150 1 0 0 537002944 8 1 123 295 8061 9790 123 85

7 12500 1 2 23650 1 0 0 67308864 8 1 140 223 8462 11150 140 76

8 57900 1 2 26700 1 0 0 67308992 8 1 93 276 9024 18800 90 48

9 47700 1 2 61650 1 0 0 33554436 8 0 153 279 5290 12950 153 67

10 31500 1 2 45650 1 0 0 67308864 8 1 134 283 8664 14150 134 61

11 41600 1 2 50800 1 0 0 67308866 8 1 140 194 8117 9200 140 98

12 46400 1 2 61650 1 0 0 33554432 8 1 183 293 9470 14550 183 65

13 23400 1 2 36750 1 0 0 33554432 8 1 133 267 8867 12350 133 67

14 46900 1 2 56150 1 0 0 33554432 8 0 160 223 8953 11150 160 80

15 34600 1 2 46500 1 0 0 67633152 8 0 226 238 8951 12900 226 75

16 9800 1 2 17950 1 0 0 148 303

17 12500 1 2 23900 1 0 0 152 79

18 59700 1 2 73200 1 0 0 119 65

19 20500 1 2 34650 1 0 0 138 66

20 27700 1 2 40350 1 0 0 120 20

21 46300 1 2 58750 1 0 0 134 70

22 38300 1 2 50550 1 0 0 151 72

23 43800 1 2 58350 1 0 0 155 62

24 50400 1 2 68300 1 0 0 203 53

25 49300 1 2 63750 1 0 0 163 60

26 42600 1 2 63300 1 0 0 142 77

27 28200 1 2 43000 1 0 0 115 61

28 50900 1 2 67250 1 0 0 124 56

29 28000 1 2 29900 1 0 0 115 71

30 3800 1 2 11150 1 0 0 121 99

31 17100 1 2 28650 1 0 0 165 74

32 38900 1 2 31550 1 0 0 126 30

33 46500 1 2 60700 1 0 0 225 66

34 52800 1 2 70500 1 0 0 173 56

35 32600 1 2 46250 1 0 0 112 55

36 49300 1 2 34150 1 0 0 536670956 8 0 44 177 55 1 133 297 8042 14950 133 62

37 57200 1 2 21750 1 0 0 67308864 8 0 48 296 53 0 150 293 9030 14650 150 62


38 43800 1 2 55850 1 0 0 67308864 8 0 46 291 22 0 186 243 9108 12050 186 76

39 55400 1 2 274150 1 0 0 536670956 8 1 26 290 57 1 131 275 9799 18750 131 52

40 11400 1 2 20900 1 0 0 33554436 8 0 40 175 36 1 163 190 8719 9500 163 92

SimWalk Database Record: 1 / 1061 35.8 MB C:\ProgramData\SimWalk 4.0\Projects\Demo_Airport\TestRun01\Database.mvn


11 Repeat step 1 and choose task 'View simulation statistics'.



12 In the 'Select a run' menu...




...choose the run 'TestRun01'.



13 In the 'Select a mode' menu...




...choose mode 'Agents speeds'.



14 The SimWalk Data Analyser opens and shows the 'Agents speeds' chart. Use the Options drop-down menu for various settings and data manipulations. Repeat step 13 to show other statistical presentations of the collected simulation data.




15 Repeat step 1 and choose task 'Run an existing simulation'.



16 In the 'Select a run' menu...




...choose the run 'TestRun01'.




17 Before starting the simulation run, you may open the Settings drop-down menu and choose 'Configuration' to configure and adapt various simulation parameters of the project.

Tip: See appendix A for details of the Configuration settings.




18 Choose the 'Options' item to set your personal 'look & feel'.


Tip: See appendix B for details of the Options settings.




19 Select the desired display mode and press [Start] button to re-run the simulation.




20 Repeat step 1 and choose task 'Replay simulation run'. Then repeat steps 16 to 19 to run existing simulation pass with the collected data from the database.




21 Repeat step 1 and choose task 'Make simulation movie' to join recorded video frames to a SimWalk movie.



22 Video window opens. In the 'Select a run' menu,



choose 'TestRun01'.



23 Select a video frame in the list to view the picture. If needed, use tool button to [Delete] selected frame(s). After setting a frame delay time [ms] and entering a name, start video creation by clicking the [Create video] button.



3. Prepare your CAD drawing for SimWalk (Full version only)

1 The first and most important task is to prepare your CAD drawing to optimize it for the requirements of pedestrian simulation with SimWalk. It is highly recommended to follow this checklist:

I. Simplify your architecture as much as possible:

- Remove all 'unused' shapes like architectural details (e.g. plants, stair treads, markers...). **Example:** Only the trunk of a tree is an obstacle for pedestrians and not the treetop - it is sufficient to only draw a small circle on the floor for the trunk instead of a big one for the whole tree.
- Signaling objects like crosswalks or road markings can be set 'marked' later in the SimWalk Drawing Board. These objects are not 'seen' by agents and will not affect the agents flow during a simulation run.
- Remove all design and dimension lines and auxiliary texts.
- Close the gaps between line endings - use closed shapes, like polylines, instead of line pieces.
- SimWalk is sensitive to lines that are not closed and don't have contact. The reason being that the potential fields - guiding pedestrians paths - rely on closed shapes for activation.
- The best way is to re-draw the outlines using polygons, rectangles, circles and polylines and delete the older lines afterwards.
- Open (or remove) all doors, gates, and turnstiles where agents should walk through; there must be a free flow from start to exit points. Gates and turnstiles will be simulated with SimWalk objects later.
- Open all stairs, elevators, and escalators - surround it with U-shaped walls.
- Remove all stairs, elevators, escalators, tracks, and vehicles - these objects will be simulated with SimWalk objects later.
- Stairs, elevators, and escalators have 3 closed walls around and just 1 open side where the agents can enter or leave (like a U-shape - see also the demo and test cases in SimWalk).
- You also can do these tasks using the SimWalk Drawing Board (SimDraw)

II. Merge your drawing layers to building levels:

- Delete all empty or not used layers.


- Place all layers exactly one upon the other.
- In SimWalk each layer must correspond with a level (a floor) of the building.
- The layer number 0 is always the bottommost level of the architecture.
- Copy the shapes from different layers to a building level.
- Move the layers in the layer list to re-sort the level order.
- Name and color your layers = levels as you like.
- You also can do these tasks using the SimWalk Drawing Board (SimDraw)

III. Save your drawing in the AutoCAD R12 format


- SimDraw can import (read only) AutoCAD drawings in the DXF R12 format.
- Before you can use your DXF drawing with SimWalk, you have to save, export, or convert it to R12 format.
- This is an older but widely used DXF format, supported by most CAD software tools and converters.

Note: The import and saving of CAD drawings is only available in the SimWalk Full Version. Drawings for import must be available in the AutoCAD R12 (.dxf) format.

2 Start SimDraw program the integrated Drawing Board of SimWalk.




3 SimDraw main window opens.




Hint: By default one layer called 'MainLayer' is already created and you are ready to draw. You may rename this layer as you like. If you want to import a drawing, the 'MainLayer' can be used as an auxiliary layer which can be deleted later.

- 4 Use tool button to [Open] SimWalk Drawing dialog. Choose drawing type 'AutoCAD R12 File (*.dxf)' and select your CAD drawing (.dxf) to import in SimDraw.




5 The 'Import AutoCAD' dialog opens. Select the AutoCAD unit, X/Y-offsets and percental scaling and rotating options to adjust your drawing after the import.

Note: It is important to save the DXF drawing with its drawing extensions (AutoCAD parameter EXTMIN and EXTMAX).




6 Your CAD drawing will be converted to the SimDraw format and shown.




A Main tool bar B Drawing tool bar C Layers list D Shapes list E Drawing status bar F Drawing area	<ul style="list-style-type: none"> - Select and control drawing and presentation - Select drawing tool - Show and control layers - Show and control shapes - Provide information about drawing and shapes - Draw and modify shapes in the drawing area
---	--

A1 Use the tool buttons to [New], [Open], or [Save] a drawing. To save the current drawing, enter a name in the SimWalk Drawing dialog or use the same name to overwrite the drawing file. Do always save drawings in the .swd file format.




A2 You may also save the drawing as a picture for documentation.




A3 Use tool buttons to [Zoom] or [Fit] the drawing or change the view to [Isometric] or [Perspective]. Press [Print] button to view all visible layers in the printer preview. Enter and adjust header and footer and set print checkboxes as you like. Use buttons to [Setup] the printer, [Cancel] or [Print] the drawing.


Note: Saving and printing a drawing is not available in the Demo version. Optional background pictures will not be printed.



A4 You can export a layer of the drawing as a SimWalk layout file (.swl).



A5 You can import an existing layout file (.swl) as a new drawing layer.




A6 Click into the layer field to open the layer selection list and then select the active layer in the pop-up menu.


Note: You can only draw and modify shapes in the currently active layer.



A7 Use the tool buttons to [Zoom to area] or to [Measure distance] in the drawing. Right-click into the drawing background or into the zoom indicator to pop-up a menu with zoom, print, import, export, properties, and settings items.




A8 Use menu buttons to set the [Pen width], [Brush style] and [Brush color] of the selected shape(s).




Hint: Notice that the pen color is determined by the layer's color.


A9 Open the [Drawing tools] drop-down menu to perform an operation on the selected shape(s). This menu also pops up with a right-click into a selected shape or into the shapes list on the right side panel. Use the tool button to [Undo] the last operation(s). Press [Layer list], [Point numbers], [Rulers], [Grid lines], or [Grid dots] buttons to show or hide the corresponding visual elements. Use the [Snap] and [Draw] buttons to make drawing and dragging shapes easier.




A10 Open Options drop-down menu to select useful tools like calculator, drawing cleaner, drawing properties, drawing settings, or drawing info. In the drawing info you can fill in optional information like your name and organisation and a short description.



A11 Select 'Cleanup drawing' item to open the Cleanup Drawing window. This tool helps to clean up the drawing by deleting unused or invalid shapes or layers.




A12 Select 'Settings' item to open the Drawing Settings window.




Tip: See appendix C for details of the drawing settings.

B1 Use tool buttons to [Select shape], [Rotate shape], [Select range], or [Select region] with the left mouse button.




B2 Click on a drawing tool button to draw the appropriate type of shape in the drawing area by dragging the left mouse button.




Tip: Use marked shapes to draw crosswalks, traffic lanes, rail tracks, stop signals, holding points, and suchlike. These shapes do not influence the pedestrian flow in a simulation but helps later to place and fit objects into the drawing like tracks or transfer areas.

B3 After selecting the line, arc, rectangle, ellipse, circle, segment, or sector drawing tool, you may double-click into the drawing area to place a shape at that position using the Draw shape tool.




B4 You can [Insert text] at any place inside the drawing to label shapes and objects. Click into the selected shape to change size, frame, alignment, and color of the text.




B5 Use [Insert bitmap image] to import external graphic symbols into the drawing. All bitmap graphic files must be found in the 'Images' subdirectory of the SimWalk data folder. Supported graphic formats are .bmp, .gif, .jpg, .png, and .ico.



B6 Use [Insert library object] to import vector graphic objects into the drawing. These drawing objects are created with SimDraw and stored in external object library files. The file name of object libraries must always end with .swo.




B7 After selecting three or more overlapping (poly)lines, you can [Join shape(s)] to a closed polygon. Use [Add node] or [Remove node] to insert or delete nodes of selected polyline or polygon. With [Cut open shape] a closed polygon can be converted to an open polyline.




B8 Use tool buttons to [Draw design line] or [Draw dimension line]. Afterwards you can move it with the left mouse button. These auxiliary lines help you to draw, place or measure shapes more precisely but are not visible in the simulation display of SimWalk.

Tip: You also may double-click into the upper side ruler to place a vertical design line or into the left side ruler for a horizontal design line.




C1 In the Layers list on the left side panel, you can add, delete, rename, resort, copy, color, activate, lock, show or hide layers. Set checkboxes to show or hide background picture and images if provided. Press [Info] button to show drawing information. Click into the color box to set the pen color of the selected layer.

Tip: Lock shape(s) or layer(s) to prevent unwanted operations.




C2 To change the layer's order click and hold the layer number and then move it up or down in the list. Use the tool buttons to [Add] a new layer or [Delete] the selected layer. Click into the layer field to change the name - then press [Rename] button to update the changes. Press the menu button to [Copy] all shapes from the selected layer to one of the layers in the drop-down list.



Important: For later use with SimWalk, each layer must conform to a level (floor) of the building, whereby the number of layers must correspond to the order of levels. The layer number 0 is always the bottommost level of the building.

D1 Using Shapes list on the left side panel, you can select one or more shapes to modify. Set checkbox(es) or drop-down menu to lock or unlock the selected shape(s).




Tip: Select the 'Delete all invalid shapes in all layers' item to remove hidden shapes outside the drawing limits or invalid shapes remaining from the CAD import. Select 'Delete duplicate points from shapes' to remove unneeded points of all shapes.

E1 In the drawing status bar, grid and drawing dimensions [m or yd], cursor position, selected shape(s), shape positions and dimensions (or rotation angle), drawing file size and name are shown.


Tip: Select the desired measuring unit and precision in the Settings (see appendix C).

F1 In the drawing area, you can draw and modify shapes in the active layer. Use the left mouse button to select a shape or drag a range (rectangular) or a region (freehand) to select multiple shapes. Now you can move or resize selected shape(s) by dragging its vertices with the left mouse button or with the arrow keys while holding down the space bar.




Tip: Notice real and relative coordinates (m or ft) in the drawing status bar.

F2 Use the 'Offset shape(s)' tool to move group of shapes to a new position.



Tip: Use the Offset tool and the Drawing settings to optimize your drawing and to fit the margins around the architecture to about 2m or yd on each side.

F3 Use the 'Scale shape(s)' tool to resize group of shapes to new dimensions.



4. Draw your own vehicles (SimWalk Transport / Airport)

1 With SimDraw it is possible to draw vehicles (trains, metros, buses, etc.), to place doors and pivots and to add them to the objects library with model name or type designation. For a realistic simulation, dimensions, doors and pivot positions must correspond to the manufacturer's specifications. The SimWalk objects library can either be built by the user or by Savannah Simulations AG as a customer service.

The following guidelines have to be followed:


- Outline of a vehicle must be a closed polygon with any number vertices.
- For inside details, any lines, polylines, rectangles or ellipses may be applied.
- Drawing line color is black and cannot be changed.
- Closed shapes can either be filled or patterned.
- The 4 outermost corner marks of all shapes define the surrounding rectangle.
- Vehicle driving direction is always from right to left.
- Doors are always drawn as longish rectangles and must be placed on the outline.
- Number of doors is not restricted but should not exceed 20.
- Doors can be drawn by using door menu with cabin classes 0...3.
- Doors are numbered in the format 'D:C' where D is the door number (1...n) and C is the cabin class (0...3). Use class 0 for non-classified cabins.
- Place odd door numbers (1, 3, 5...) on the left side (in driving direction).
- Place even door numbers (2, 4, 6...) on the right side (in driving direction).
- Vehicles without doors cannot transport passengers, but can make sense to represent locomotives, engines or freight wagons.
- Pivot points are drawn as small circles and must be located on the center line of the vehicle - they are consecutively numbered from left (1) to right (4).
- The 4 pivots can be drawn by using the pivot menu.
- Pivot 1 is the front coupler pivot and headmost point of the vehicle. It assigns the principal pivot for start/stop positions on respective tracks.
- Pivot 2 is the front axle pivot which is coinciding with the track.
- Pivot 3 is the rear axle pivot which is coinciding with the track.
- Pivot 4 is the rear coupler pivot and the sternmost point of the vehicle.

- It is conceivable and valid that the two left and/or the two right pivots are lying one upon each other, e.g. if two coupled wagons shares one bogie to build an articulated vehicle.
- Reserved object names like 'stair', 'elevator', 'escalator', 'door' or 'pivot' are not allowed. Do not use a name like an existing vehicle.
- Vehicle names should only have characters 'A'...'z', numbers '0'...'9', and underline '_'
- The default object library is called 'SimWalk.swo' and must be found in the SimWalk data folder.
- You can modify and save your objects library as a user-defined file (always with the ending .swo).
- You can handle any number of objects libraries, e.g. for each project or customer. Then in SimWalk you can select the desired library file in the Configuration of your project.
- Vehicle parameters can be defined by using the property editor (see below).

Hint: The same way you can create standard objects like trees, furniture, traffic lights and so on. These objects have neither doors nor pivots, but can also be imported into all types of SimWalk drawings.


Important: Do not modify, rename, or delete existing objects in the library! Do only work with your self created vehicles. The objects library file name must end with .swo.

- 2 Start the SimWalk Drawing Board. Use tool button to [Open] SimWalk Drawing dialog. Choose drawing type 'SimWalk Objects (*.swo)' and select the objects library 'SimWalk.swo' in the SimWalk data folder.




3 Drawing board is opening and library objects are shown on the right side as small symbols in the objects panel. Click on a symbol and modify vehicle or begin drawing a new one using the drawing tools on the left side.

Hint: Some drawing functions and tools are not available for objects, whereas the door and pivot tools and the vehicle properties are solely for vehicle objects.




If you have a 3D license, an additional 3D viewer opens showing the 3D model of the vehicle (if available). Use [3D-view] to show or hide the 3D model.



- 4 After drawing the vehicle's outline, 4 pivot points must be placed. Select pivots 1 to 4 from the menu and place it on the centerline of the vehicle from left to right. The pivots represent the vehicles coupler and rotation axis.


Tip: Select the vehicle and use the 'Show center lines' function and/or the design line tools to draw auxiliary lines for easier and more precise pivot and door placement. Use the 'Center...' and 'Align...' functions to bring the selected shapes into line.

Hint: Size and color of pivots cannot be changed.




- 5 Select a door class from the door menu and place it on the vehicle outline at the right location. Use drawing tools to move, resize, rotate, or delete a door. Repeat this step for all vehicle doors.

Hint: Color of doors cannot be changed.




6 Select the 'Set vehicle door size' item to open the Vehicle Door tool. Set the width, height, and elevation (height above floor) of the door(s) in cm or in (depending on the drawing unit) and press [Apply] to change the size of all selected doors.



Hint: Height and Elevation are only used for 3D objects.

7 After drawing a vehicle, you can fill in vehicle properties on the right side panel. Click into a field and enter the value specified by the producer. Using Properties dropdown menu you can add, delete, cleanup, or preset vehicle data.




Hint: The following parameters are used in SimWalk:

- Producer Name of the vehicles manufacturer
- Type Vehicle type like 'Bus', 'Railcar', 'Wagon', or 'Engine'
- Capacity Max. number of passengers having place inside the vehicle
- Speed Driving velocity (m/s) of the arriving/departing vehicle
- Delta De-/Acceleration (m/s²) of the arriving/departing vehicle


8 To add a new vehicle to the objects library, enter a unique name and press the [Put] button. To update a vehicle, press the [Put] button but leave the name as before. To rename a vehicle, just retype name and press the [Update] button. If the name is empty, you can [Delete] the vehicle from the library.

Tip: Use a meaningful name like the vehicles model number or type designation.


Hint: The small lamp on the right side of the vehicle name will light up to indicate that a vehicle has been modified but is not yet saved in the objects library.




9 To create a new vehicle from scratch, open the 'New object' menu and select the 'New vehicle object' item.




10 Press the [Import] button to open the 'Import SimWalk Objects' dialog where you can select an objects file (.swo) to add predefined vehicle(s) to your objects library.



11 After selecting an object file, Import Objects windows opens and shows all available vehicles. Select those vehicles you want to import and press the [Import] button.




12 Use the [Export] button to save the currently loaded vehicle to an object file (.swo).



13 A 3D license allows creating simple 3D models of vehicles (and other objects). The following steps show a fast and easy way how to create a 3D model.


- Select one or more shapes having the same attributes (e.g. the same material)
- Optionally press button to [Show point numbers]
- Lock these shapes (press both keys <Ctrl-L> or use the pull-down menu)
- Move the mouse cursor over a red corner point - cursor changes to 3D cube
- Click the red point (or just press the <Insert> key) - the 3D Points Editor opens
- For each point enter its H- (height) and Z-values (elevation).
- If values are equal press button to [Fill Z- or H-column with selected value]
- You also can enter Floor (Z) and Height (H) assigning to all red points
- Select one of the predefined materials or a texture to cover the shape(s)
- Press the [Add] button to put the selected shape(s) to the 3D world
- Press the [Delete] button to remove the selected shape(s) from the 3D world
- Repeat these steps for all shapes



Please regard the following hints:

- The 3D model will be saved as a SimWalk 3D Binary file (.swb) if the [Save] button is pressed to save the objects library
- All 3D models must be located in the '\Virtual\Models' subdirectory of the SimWalk data folder
- Textures must be found in the '\Virtual\Textures' subdirectory of the SimWalk data folder. Supported graphic formats are .bmp, .gif, .jpg, and .png.
- Define materials in the <materials> section of the 'defaults.swc' file
- 3D-Easy models can be replaced by more sophisticated models from other 3D modeling software. Supported 3D formats are .x (DirectX) and .3ds (AutoCAD 3D Studio).
- 3D-Studio files (.3ds) have to be converted using Sim3DS.exe

14 Use tool buttons to [Save] the objects library or make a picture of the currently loaded object.



5. Draw your own devices (SimWalk Airport only)

With SimDraw it is possible to draw so-called devices and to add them to the objects library with model name or type designation. Devices are compound objects consisting of geometric shapes and control objects. They are used to emulate standard terminal facilities like ticket counters, access and security controls, check-ins, passport controls, boarding gates, baggage handling, snack bars, and kiosks and so on. For a realistic simulation, all dimensions and properties must correspond to the manufacturer's specifications. The SimWalk objects library can either be built by the user or by Savannah Simulations AG as a customer service.

The following guidelines show the way of proceeding:


- Draw the housing of the device using standard shapes like lines and rectangles.
- For construction details (e.g. railings or swing panels), any lines, polylines, rectangles or ellipses may be applied.
- Drawing line color is black and cannot be changed.
- Closed shapes can either be filled or patterned.
- Place any number of control objects (max. 9 of the same type) and fit them into place.
- Define the object's properties which control the device behavior (e.g. pedestrian throughput rate or queue length).
- Draw optional hidden lines (invisible guiding elements) to control the pedestrian flow.
- Put the device (back) into the objects library and save it.
- Reserved object names like 'stair', 'elevator', 'escalator', 'door' or 'pivot' are not allowed. Do not use a name like an existing object.
- Device names should only have characters 'A'...'z', numbers '0'...'9', and underline '_'
- The default object library is called 'SimWalk.swo' and must be found in the SimWalk data folder.
- You can modify and save your objects library as a user-defined file (always with the ending .swo).

- You can handle any number of objects libraries, e.g. for each project or customer. Then in SimWalk you can select the desired library file in the Configuration of your project.

Hint: The same way you can create standard objects like trees, furniture, traffic lights and so on. These objects do not have control objects, but can also be imported into all types of SimWalk drawings.


Important: Do not modify, rename, or delete existing objects in the library! Do only work with your self created devices. The objects library file name must end with .swo.

- 2 Start the SimWalk Drawing Board. Use tool button to [Open] SimWalk Drawing dialog. Choose drawing type 'SimWalk Objects (*.swo)' and select the objects library 'SimWalk.swo' in the SimWalk data folder.




- 3 Drawing board is opening and library objects are shown on the right side as small symbols in the objects panel. Click on a symbol and modify device or begin drawing a new one using the drawing tools on the left side.

Hint: The door and pivot tools are solely for vehicle objects.




If you have a 3D license, an additional 3D viewer opens showing the 3D model of the vehicle (if available). Use [3D-view] to show or hide the 3D model.



4 After drawing the device's geometry, control objects can be placed. Select an object from the menu, place it on the device and fit it into place. The figure below shows a self-boarding gate consisting of the device's geometry (ticket console, glass panels...) and two

control objects - a delay area (orange) and a turnstile (green). Regard the pass-through direction of the turnstile indicated by the small arrows.




Tip: Select the design line tools to draw auxiliary lines for easier and more precise object placement. Use the 'Center...' and 'Align...' functions to bring the selected shapes into line.

Following a short description of currently available control objects:

- Start area - Locations where pedestrians entering the simulation scenario
- Exit area - Locations where pedestrians leave the simulation scenario
- Waiting area - Area where pedestrians are remaining some time, e.g. on a ticket counter or baggage handling where travelers can check-in or reclaim their baggage.
- Delay area - Reduce the speed of pedestrians walking in that area, e.g. to emulate a ramp, a waiting queue, or a man conveyor.
- Gate - Allow many pedestrians to pass at defined time intervals, e.g. for an access control or traffic light at pedestrian crossings.
- Turnstile - Acts as a pedestrian separator, letting through only one pedestrian every specified service (delay) time, e.g. for a point of payment or a ticket control.
- Counter - Counts the number of pedestrians passing the line in the defined counting direction (left-right, right-left, or bidirectional).
- Meter - Area defined as a simple polygon, counting either the number of pedestrians inside (load) or the density (P/m^2).


5 After placing a control object, you can adjust the object properties on the right side panel. Click into a given field and select or enter the desired value.

Hint: You are able to modify these parameters later in your simulation model (SimWalk).



Note: The property name is predefined and can not be changed. The naming convention is 'XN:Label' where X is the first character of the control object type (e.g. 'T' for 'Turnstile'), N is a consecutive number from 1 to 9, and ' Label ' is the parameter notation. The row color is equal to the object's color defined in the Options of SimWalk. You can disable the table coloring in the Properties drop-down menu (see below).


6 After drawing the device, you can fill in the device properties on the right side panel. Click into a field and enter the value specified by the producer. Using Properties drop-down menu you can add, delete, cleanup, or preset device parameter.




7 To add a new device to the objects library, enter a unique name and press the [Put] button. To update a device, press the [Put] button but leave the name as before. To rename a device, just retype name and press the [Update] button. If the name is empty, you can [Delete] the device from the library.

Tip: Use a meaningful name like the device model number or type designation.


Hint: The small lamp on the right side of the device name will light up to indicate that a device has been modified but is not yet saved in the objects library.




8 To create a new device from scratch, open the 'New object' menu and select the 'New device object' item.




9 Press the [Import] button to open the 'Import SimWalk Objects' dialog where you can select an objects file (.swo) to add predefined device(s) to your objects library.



10 After selecting an object file, Import Objects windows opens and shows all available devices. Select those devices you want to import and press the [Import] button.




11 Use the [Export] button to save the currently loaded device to an object file (.swo).



12 A 3D license allows creating simple 3D models of devices (and other objects). The following steps show a fast and easy way how to create a 3D model.


- Select one or more shapes having the same attributes (e.g. the same material)
- Optionally press button to [Show point numbers]
- Lock these shapes (press both keys <Ctrl-L> or use the pull-down menu)
- Move the mouse cursor over a red corner point - cursor changes to 3D cube
- Click the red point (or just press the <Insert> key) - the 3D Points Editor opens
- For each point enter its H- (height) and Z-values (elevation).
- If values are equal press button to [Fill Z- or H-column with selected value]
- You also can enter Floor (Z) and Height (H) assigning to all red points
- Select one of the predefined materials or a texture to cover the shape(s)
- Press the [Add] button to put the selected shape(s) to the 3D world
- Press the [Delete] button to remove the selected shape(s) from the 3D world
- Repeat these steps for all shapes



Please regard the following hints:

- The 3D model will be saved as a SimWalk 3D Binary file (.swb) if the [Save] button is pressed to save the objects library
- Control objects are neither used nor seen in 3D
- All 3D models must be located in the '\Virtual\Models' subdirectory of the SimWalk data folder
- Textures must be found in the '\Virtual\Textures' subdirectory of the SimWalk data folder. Supported graphic formats are .bmp, .gif, .jpg, and .png.
- Define materials in the <materials> section of the 'defaults.swc' file
- 3D-Easy models can be replaced by more sophisticated models from other 3D modeling software. Supported 3D formats are .x (DirectX) and .3ds (AutoCAD 3D Studio).
- 3D-Studio files (.3ds) have to be converted using Sim3DS.exe

13 Use tool buttons to [Save] the objects library or make a picture of the currently loaded object.




6. Create your own simulation project (Full version only)

Having stored your CAD drawing in the SimWalk drawing format (.swd), you are now ready to create your own project. It is highly recommended to follow this checklist:

1. Make a concept (print out the drawing and plan waypoints and walking routes before beginning with the implementation).
2. Create a new project and import your SimWalk drawing.
3. Place waypoints in your architecture (start areas, exit areas, waiting areas).
4. Place inter-level objects (stairs, elevators, and escalators).
5. Place control objects in your architecture (delay areas, gates, and turnstiles).
6. Place counting objects in your architecture (counters, load or density meters).
7. Place device objects in your architecture (SimWalk Airport only)
8. Place transport objects in your architecture (platforms, tracks, and vehicles).
9. Build transport formations (group vehicles and assign tracks and platforms).
10. Build the agents plan (schedule agents walking paths and transport timetables).
11. Run your simulation (make multiple runs to optimize your project and settings).
12. Analyse simulation results to verify your concept and find critical areas.
13. Create the documentation of your simulation (report, diagrams, pictures, movies...).

Note: Creating your own projects is not available in the Demo version. Points 7 to 9 are only available in SimWalk Transport / Airport. Use optional points 4 to 9 if required.


1 Using 'Select a project' menu, choose last command 'Create new project'.



2 New Project dialog is opening. Enter the name of your project and select the desired unit system (Metric or Imperial). Optionally you can [Select an icon] for your project. Then click into the Project drawing field to open SimWalk drawing dialog. Choose your drawing file (.swd) and press the [Create] button. A new project folder will be created and


the drawing file is split into layout files (.swl). For each layer (conforms to a level) in your drawing a layout file in XML format is created.

Important: From now on SimWalk only works with these layout files. If you make changes in the drawing file (.swd) you have to repeat the project creation (step 1).




Hint: The number of available project creations depends on your purchased license and is shown in brackets in the new project dialog title bar. The video width determines the image resolution in pixels of potential fields dumped after a simulation run (if selected in the Configuration).

- 3 If project creation was successful, you can select 'View project drawing' task and level files are displayed colored as defined in SimDraw. Display handling is described in chapter 1. Using 'Select an object' menu, choose 'Start areas' item. Start areas define where agents are generated in the layout according to a given simulation scenario.



Tip: Use the [Draw design line] function to draw auxiliary lines which can help to place objects like areas or tracks. Zoom into the drawing to bring out finer details.


- 4 Choosing 'Select a level' menu activate the level you would like to prepare first.




Note: There are many test cases to demonstrate the functions of the different objects.

- 5 Click the right mouse button to place a new start area. A small polygon with 4 vertices is inserted at the cursor position. Press [Add] button to lock the object into position.


Note: The size of the shape is always the same independent of the current zoom factor. All area and meter polygons must be simple, consisting of 4 non-intersecting line segments.



6 The start area is now added to the Parameter table. All SimWalk objects of the layout file (.swl) are handled via the Parameter table. Use tool buttons to [Save], [Delete], [Find], [Edit], [Import], [Export], or [Print] the table data. Open the Options drop-down menu to select items for various settings and functions.




7 Now you may move or resize selected start area by dragging the vertices (green corner points) with the left mouse button or the arrow keys while holding down the space bar. Place the caption (green center rhomb) in the same way as you like.



Tip: Regard the real position coordinates (m or ft) in the Display status bar.

8 Enter a meaningful, unique name for the start area and then press [Update] button. The right button is used to toggle drawing modes between [Rotate] and [Move]. Color and shape of the vertices and button icon are changing accordingly.



9 Using Parameter table, press [Save] button to write all table data to the layout file.

Parameter

Start areas

Save parameter

1 / 5 modified C:\ProgramData\SimWalk 4.0\Projects\Railway Station\MainLevel.csv

ID	Name	X	Y	X1	Y1	X2	Y2	X3	Y3	X4	Y4	Tx	Ty
1	Car Parking South	71.68	64.13	68.90	62.54	78.69	59.34	80.19	63.57	63.52	68.92	71.68	64.03
2	Bus Terminal	9.67	13.00	8.00	11.33	11.33	11.33	11.33	14.67	8.00	14.67	9.67	13.00
3	City Entrance East	10.33	24.00	8.67	22.33	12.00	22.33	12.00	25.67	8.67	25.67	10.33	24.00
4	City Entrance West	9.67	31.00	8.00	28.33	11.33	28.33	11.33	32.67	8.00	32.67	9.67	31.00
5	Shopville	13.67	40.00	12.00	38.33	15.33	38.33	15.33	41.67	12.00	41.67	13.67	40.00

Tip: Keep in mind to save regularly for not loosing data.

10 All placed areas are listed in the Parameter table. You may select a start area either by clicking into a shape in the layout or into a row of the Parameter table. Use the tool buttons to [Delete] or [Update] the selected start area.

SimWalk Airport Vers. 4.0 - Copyright by Savannah Simulations AG

Railway Station

View project drawing

Network disabled Database server Simulator engine

Start areas

MainLevel

Legend

Level Color Name

1 (unchecked) Bridge

0 (checked) MainLevel

Start areas

Bus Terminal

Car Parking South

Level 0 242 x 110m

Railway Station - MainLevel (Start areas)

Parameter

Start areas

Save parameter

1 / 5 modified C:\ProgramData\SimWalk 4.0\Projects\Railway Station\MainLevel.csv


ID	Name	X	Y	X1	Y1	X2	Y2	X3	Y3	X4	Y4	Tx	Ty
1	Car Parking South	71.68	64.13	68.90	62.54	78.69	59.34	80.19	63.57	63.52	68.92	71.68	64.03
2	Bus Terminal	9.67	13.00	8.00	11.33	11.33	11.33	11.33	14.67	8.00	14.67	9.67	13.00
3	City Entrance East	10.33	24.00	8.67	22.33	12.00	22.33	12.00	25.67	8.67	25.67	10.33	24.00
4	City Entrance West	9.67	31.00	8.00	28.33	11.33	28.33	11.33	32.67	8.00	32.67	9.67	31.00
5	Shopville	13.67	40.00	12.00	38.33	15.33	38.33	15.33	41.67	12.00	41.67	13.67	40.00

11 Use the export function if you want to save your parameter table as an Excel or text file.



New: Save as XML (UTF-8) or XLSX for vast amount of data. Excel before 2007 (XLS) is limited to 65'536 rows - extended XLSX format allows export of over a million rows.

12 Use the import function to load an external Excel or text file into the parameter table.




13 Repeat the steps 3 to 13 and select the objects 'Exit areas'. Exit areas are locations where pedestrians leave the simulation scenario. To get a probabilistic outcome of exit choices (agents choose the nearest exit) you may label exit areas with identical names. The simulation algorithm calculates the fastest way to an exit area for every agent. There are the following parameters to control the behavior of an exit area:

- Capacity Max. number of pedestrians having place inside the area

- Frequency Time interval exit area opens to enter (in seconds)
- Open time Duration where the area is open to enter (in seconds)
- Normal exit Last waypoint where pedestrians leave the simulation scenario
- Emergency exit Exit normally closed but opened in case of a hazard (e.g. fire alarm - see step 20). Only available if the 'Evacuation' feature is enabled.

Hint: In most cases, you can use the default values.



14 Repeat steps 3 to 12 and select object 'Waiting areas'. Waiting areas are used as


- Waypoints to define a pedestrian walking path (route)
- Meeting areas where pedestrians are remaining some time (e.g. in a restaurant or a ticket office)
- Baggage handling to check-in and/or reclaim travel baggage
- Transfer areas where passengers are waiting for their transport formation (e.g. a platform of a train station).

There are the following parameters to control the behavior of a waiting area:

- Capacity Max. number of pedestrians having place inside the area
- Frequency Time interval where the area opens to enter (in seconds)
- Open time Duration where the area is open to enter (in seconds)
- Meeting area Area appears as a waypoint in the Agents plan builder
- Transfer area Area appears as a platform in the Formation builder

Hint: Transfer areas are only available in SimWalk Transport / Airport. Capacity, frequency, and open time parameters are only used for special meeting areas. In most cases you can use the default values. The effective time (in seconds) the agents are remaining in

a waiting area and baggage handling are defined later in the Agents plan builder (see point 37 below).




Tip: You can combine 2 or more waiting areas giving all the same name to model complex architectures like curved platforms or shapeless geometries.

15 Repeat steps 3 to 12 and select object 'Delay areas'. Delay areas are used to reduce the speed of pedestrians walking in that area e.g. to simulate a ramp, a waiting queue, or a man conveyor. You can place delay areas over the architecture. There are some parameters to control the behavior of a delay area:

- Speed limit Max. walking speed of all pedestrians (in cm/s)
- Speed reduction Percental speed reduction for each pedestrian (in %)
- Utilization time Duration for a pedestrian to transit the area (in seconds)


Hint: The utilization time is always just estimation because of the unknown walking route of the pedestrians. The walking direction inside the delay area is not relevant.




16 For multi-level projects, SimWalk supports inter-level objects like stairs, elevators, and escalators which allow pedestrians to change from one level to another. Repeat steps 3 to 12 and select objects 'Stairs' (use the same procedure for 'Elevators' and 'Escalators'). Select the next upper and/or lower level where the stair should connect. Then enter a meaningful unique name and press [Add] button. There are the following parameters to control the behavior of a stair:

- Capacity Max. number of pedestrians having place on the stair
- Frequency Time interval the stair is open to enter (in seconds)
- Speed reduction Percental speed reduction for each pedestrian (in %)
- Utilization time Duration for a pedestrian to transit the stair (in seconds)

Hint: For general purposes you can use the default values.




17 Move, resize, and rotate the stair to fit it in the architecture. Repeat steps 16 and 17 to place and name all stairs on the actual level. Do not forget to save the Parameter table.




Important: An inter-level object should have 3 walls around it, forming a U-shape, and just 1 open side where the pedestrians can enter or leave. The gap between the object and the surrounding walls should be in the range of 5..50 cm (2..25 in).

18 To place corresponding stairs on other levels, change the active level (point 4), insert a new stair and select the upper or lower level (point 16). But now, do not enter a new name but select the name of the corresponding stair found in the drop-down list.



19 To make sure that both stairs are lying exactly upon each other, click 'Align vertical' checkbox and press the [Add] button, then the stair will be immediately aligned.




Tip: To control the movement direction of an escalator, you just have to assign one level (where the pedestrians can enter) and let the other empty (where the pedestrians come out).


Tip: See Appendix F for the elevator timing diagram.

20 If the 'Evacuation' feature is enabled, you are able to define one or more hazards in your simulation scenario. A hazard simulates an emergency situation like fire or explosion. Agents inside the action radius of a hazard realize the danger and run away to the next emergency exit. Agents inside the danger zone (the orange circle drawn with the mouse) are greatly influenced by the hazard (injured or dead) and therefore no longer in the simulation. Hazard activation can either be manual or time controlled. Repeat steps 3 to 12 and select objects 'Hazards'. Enter a meaningful and unique name and press [Add] button. The following parameters control the behavior of a hazard:

- Trigger time Start of the trigger time range (in seconds)
- End of range End of the trigger time range (in seconds). The effective trigger time is chosen randomly from this range. Set both times to the same value to schedule a hazard. If both times are 0 (zero), the hazard must be activated manually (using the hazard control).
- Action zone Invisible round area where agents realize the hazard (in m)
- Symbol image Optional graphic symbol to place elsewhere in the layout
- Emergency exit Select the appropriate emergency exit from the list



21 SimWalk offers two control objects, 'Gates' and 'Turnstiles', to simulate gate and turnstile behaviors. Both objects are very similar and both include the option to count passing pedestrians. A turnstile acts as a pedestrian separator, letting through only one pedestrian every specified service (delay) time (e.g. for a point of payment, a ticket control, or a revolving door). On the other hand, a gate has additional 'Open time', 'Offset', and 'Frequency' settings, allowing many pedestrians to pass (e.g. for an access control or traffic lights at pedestrian crossings). Repeat steps 3 to 12 and select object 'Gates' (use the same procedure for 'Turnstiles'). Enter a meaningful and unique name and the control times. Then select the counting and opening direction (left-right, right-left, or both for bidirectional) and press the [Add] button.




Hint: The pass-through direction is indicated by 2 small arrows at the corner points.

During a simulation run, the color of a gate changes with the current state (if enabled in the Options). Red means the gate is closed and green indicates an opened gate.

Tip: See Appendix G for the gate timing diagram.


22 There are two counting objects with SimWalk that don't interact with pedestrians. A 'Counter' is similar to a turnstile, but only counts the number of pedestrians passing the line between both vertices. The counting direction (left-right, right-left, or bidirectional) is indicated by 2 small arrows at the corner points. A meter is an area defined as a simple polygon with for vertices, counting either the number of pedestrians inside (load) or the density (P/m^2 or P/yd^2). Optionally the area color changes according the current level of service (LoS). Repeat steps 3 to 12 and select objects 'Meters' (use same procedure for 'Counters'). Enter a meaningful and unique name and select the mode.



23 Introduced in Version 4.0, SimWalk Airport provides support for device objects. Devices are compound objects consisting of geometric shapes and control objects. They are used to emulate standard terminal facilities like ticket counters, access and security controls, check-ins, passport controls, boarding gates, baggage handling, snack bars, and kiosks and so on. Devices must be drawn with SimDraw program and are stored in the objects library (see chapter 5). Repeat steps 3 to 12 and select objects 'Devices'. Select the desired device model from the list, enter a meaningful and unique name and press [Add] button. Use the mouse to move the device to bring it in position.


Hint: Devices has a fix size and can not be resized inside the layout.

In the figure below you see 5 identical devices, each consisting of a delay area and a turnstile to emulate a self-boarding gate.




All control objects from a device are also listed in the associated Parameter table. In the figure below, you see the delay area 'D1' of the device 'GateA1'. It appears in the Parameter table as 'GateA1*D1'. The asterisk (*) inside the object name indicates that the delay area belongs to a superior device.

Hint: Device control objects can neither be moved nor resized, hence the corner points are not green but orange. Only the object's caption position (orange rhomb) and control parameter (e.g. the delay time) can be altered.



Hint: If the desired device model is not available, see chapter 5 how to add a device to the library or contact Savannah Simulations AG for service and support.


24 Furthermore, SimWalk Transport / Airport supports both objects tracks and vehicles to emulate trains or metros, trams, busses, taxis, or any other kind of transportation carriages. A track is a series of line segments (polyline) that a dynamic vehicle can follow. Static vehicles are not moving and do not need a track (see vehicles below). A track has always a start and an end point and can have 2 or more nodes in between. If the start and the end point are identical, then the track is closed (e.g. for a circular path). Tracks are 'invisible' for pedestrians - therefore they are not seen as an obstacle. Repeat the steps 3 to 12 and select objects 'Tracks'. Enter a meaningful and unique name and press [Add] button.




Tip: Design lines and hidden shapes like the light gray tracks in the figure above helps you to draw and fit objects into your layout.

25 Move nodes with the left mouse button to fit the track in your architecture and determine where the formation(s) stops. Use the tool buttons to [Insert] or [Delete] nodes, or [Close] the track.

Hint: The track node numbers are later used by the Formation builder to determine the stop position and the arriving and departing direction of the vehicle formation.




26 A vehicle is an object which can transport agents (passengers). It can act as a start area (arrival) and/or as an exit area (departure). Vehicles are combined objects consisting of doors, pivots and a user-defined shape to look like the original. Vehicles must be drawn with SimDraw program and are stored in the objects library (see chapter 4). Repeat steps 3 to 12 and select objects 'Vehicles'. Select vehicle model from the list and set capacity as well as number of seats as desired.




Hint: The seats parameter is for future use and currently ignored. If the desired vehicle model is not available, see chapter 4 how to add a vehicle to the library or contact Savannah Simulations AG for service and support.

27 Enter a vehicle group (a meaningful composition name) and press the [Add] button. The simple rectangle will be replaced by the vehicle from the library. If the composition consists of more than one vehicle (e.g. a train), add additional vehicles of the same and/or different model and select always the same vehicle group. All vehicles of the same group build a composition (multiple units). Dynamic vehicles can be placed elsewhere - they follow a track and stop at a node on this track. Static vehicles must be placed exactly at the position where they stop for boarding/alighting. Use tool button to [Link] the vehicles together if you move a vehicle's coupler in the near of another (ca. 1m or yd). You will hear a 'click' sound if two vehicles are coupled. In the figure below you see a composition containing 2 railcars and a passenger wagon whereby the right vehicle was rotated by 180°.

Important: The placing sequence of the vehicles is decisive. The first is called the leading vehicle (engine or locomotive) which foremost coupler (principal pivot 1) determines the driving direction and the stop position (node) on a track.




28 The stop position of the leading vehicle and the composition length must correlate with the track stop node and the transfer area (platform). Each door should be opposite the platform. Repeat step 14 and readjust the transfer areas if needed.




Tip: Press button to [Overlay] hidden objects like transfer areas, tracks, and nodes.

29 After the successful definition of platforms, tracks, and vehicles, you are ready to build formations. Using 'Select a task' menu, choose task 'Build transport formations'.




30 Formation builder opens. In the 'Select a level' menu, choose the first level containing vehicles.


Hint: The Formation builder is only available in SimWalk Transport / Airport.



31 Using 'Select a composition' menu, choose the desired composition.



32 The composition with all its vehicles and predefined passenger profiles are shown in the table. Using 'Select a platform' menu, choose a specific platform.



33 Using 'Select a track' menu, choose a specific track.

Hint: This and the next steps are only needed for dynamic (driving) vehicle formations; otherwise set the 'Static formation' checkbox.



34 If you have selected a track, you can determine the stop node and the arriving and departing direction of the formation on this track. First select the node where the formation comes from (the track node before arrival), then the node where the formation stops, and last the node where the formation goes to (the next node after departure). It is evident that for a terminus the arrival and departure node are the same.

Arrival —> Stop —> Departure			
2	3	4	
0			
1	Vehicle03		5
2	3 (2)	4 (2)	
3	100	100	100
4	0	0	0

35 When completed, press the [Formation name] button to enter a meaningful and unique formation name. At last press the <Enter> key to complete the input. Finally [Save] the formation. Optionally you can [Select an icon] for your formation.

Driving speed (m/s) as well as de-/acceleration (m/s^2) of the formation are taken from the vehicle library but can be adjusted here. The checkbox 'Agents interaction' must be set if the formation crosses pedestrian ways (e.g. a tram or a baggage cart in a station).

An already existing formation can be loaded by selection a formation from the list. Use the buttons to [Delete] a formation or reset the passenger allocation to its [Default] values.

Save formation

Level	Composition	Platform	Track	Arrival —> Stop —> Departure									
MainLevel	Metro 512	Platform North	Track North	2 3 4									
Passengers	Vehicle01				Vehicle02				Vehicle03				Sum
Profile \ Door (Class)	1 (1)	2 (1)	3 (2)	4 (2)	1 (2)	2 (2)	3 (2)	4 (2)	1 (1)	2 (1)	3 (2)	4 (2)	Sum
Everyman	100	100	100	100	100	100	100	100	100	100	100	100	100
Commuter	0	0	0	0	0	0	0	0	0	0	0	0	0
SportFans	0	0	0	0	0	0	0	0	0	0	0	0	0
Shopper	0	0	0	0	0	0	0	0	0	0	0	0	0
Traveler	0	0	0	0	0	0	0	0	0	0	0	0	0
Rescue	0	0	0	0	0	0	0	0	0	0	0	0	0
Hooligans	0	0	0	0	0	0	0	0	0	0	0	0	0
Juveniles	0	0	0	0	0	0	0	0	0	0	0	0	0
Flyers	0	0	0	0	0	0	0	0	0	0	0	0	0
Total allocation	8.33	8.33	8.33	8.33	8.33	8.33	8.33	8.33	8.33	8.33	8.33	8.33	10

Edit formation name

Formation: Metro 512 Lausanne

Driving speed: 90 km/h

Delta speed: 0.8 m/s²

Agents intercation:


Static formation:

36 In the formation table, you can set the percentage of passenger allocation per vehicle door (or cabin). In the columns, vehicles with their doors (and class in brackets) are shown. In the rows respectively, the passenger profiles are listed. Click into a field and enter a value between 0 and 100% to change passenger allocation for the corresponding door. The maximum per door (per column) is limited to 100% but less can make sense (if a cabin is not fully occupied). In the last row, the total percentage door allocation is shown. Press the

[Save] button again to update the changes. The schedule and effective number of passengers in the vehicles are determined by the Agents plan builder (see step 39 below).


Passengers	Vehicle01					Sum
	1 (1)	2 (1)	3 (2)	4 (2)	1 (2)	
Profile \ Door (Class)	1 (1)	2 (1)	3 (2)	4 (2)	1 (2)	%
Everyman	75	75	75	75	75	73.8
Commuter	25	25	25	25	25	25.0
SportFans					0	0.00
Shopper					0	0.00
Traveler	15	0	0	0	0	1.25
Rescue	0	0	0	0	0	0.00
Hooligans	0	0	0	0	0	0.00
Juveniles	0	0	0	0	0	0.00
Flyers	0	0	0	0	0	0.00
Total allocation	8.33	8.33	8.33	8.33	8.33	100.0

37 Use the export function if you want to save your formation table as an Excel or text file.




New: Save as XML (UTF-8) or XLSX for vast amount of data. Excel before 2007 (XLS) is limited to 65'536 rows - extended XLSX format allows export of over a million rows.


38 Use the import function to load an Excel or text file into the formation table.



39 The last step is to build the agents plan. Using 'Select a task' menu, choose task 'Build agents plan'.




40 Agents plan builder and Parameter table opens.




41 The first step always consists in selecting a start point. Using 'Select a start point' menu, choose one of the listed start points and enter a start time range. Depending on the selected time format, you can enter the runtime in seconds or the clock time in the format 'hh:mm:ss'. Set checkboxes if you want to show pending agents in the start area and/or let agents start with travel baggage (if assigned by profile).

Hint: Formations in the start point list are highlighted but only available in SimWalk Transport / Airport.




42 The next step consists - if needed in the simulation scenario - in selecting a waiting point. Using 'Select a waiting point' menu, choose one of the listed waiting points and enter the number of agents in this group.

Hint: Only meeting areas (see step 14) are in the selection list. If no waiting point(s) are foreseen, go to step 45 and enter the last exit point.



43 Enter the waiting time range (in seconds). These values can be equal. Set both to 0 (zero) if the pedestrians should not wait but only pass the waypoint. Set checkboxes if the waypoint may be used to check-in and/or reclaim travel baggage. Then select the appropriate agents profile for this agents group.




44 Press [Add] button to add agents to the Parameter table. Repeat steps 41 to 44 for each waypoint.



Tip: It is recommended to conduct your first simulation run with just a few agents to verify your concept and to check if the potential fields of the waypoints can be built without problems.

45 The last step is always to select an exit point. In the 'Select an exit point' menu choose one of the listed exit points.

Hint: Formations in the exit point list are highlighted but only available in SimWalk Transport / Airport.



46 If the last exit point is a formation, you also have to enter the arrival and departure time (in seconds or clock format). Set the parameters 'Door closing' (time to wait before departing after the doors has closed) and 'Departure delay' (max. time the formation waits if not yet all passengers are aboard) as desired. If the exit point is not a formation, then these times are ignored. Press [Add] button to add the agents to the Parameter table.

47 If the start point is a formation, you have to enter the arrival and departure time (in seconds or clock format) instead of a start time range. Set the parameters 'Door opening' (time to wait before the door opens and passengers can go out after holding) and 'Arrival variation' (random spread the arrival time \pm a few seconds around the planned time) as desired. The profile is given by the formation. The simplest case with 1 start point, no waiting point, and 1 exit point is shown in the figure below.

Tip: See Appendix H for the formation timing diagram.

48 Repeat steps 41 to 47 for each additional agent group. Depending on the complexity of your project, this may be a time consuming process. It is recommended to make a concept in advance for not to loose oversight. In the Parameter table, press the [Save] button to write the table data into the template file 'agents_00'. The template number will be increased every time you create a new agents plan. These templates can be used later to rebuild an agents plan.

Tip: Keep in mind to save at regular intervals for not loosing data.

Agents

Next step: Start point: City Entrance West (Mainlevel) Start time: 07:00:00 to 07:05:00 Door opening: 2 ± 0 Arrival variation: 0 ± 0

Next step(s): Waiting point: Waiting time: 0 to 0 Door opening: Travel luggage check-in: Travel luggage return: 0 ± 0

Last step: Exit point: Metro S12 Lausanne (Platform South) Arrival time: 07:06:00 to 07:09:30 Departure time: 07:06:30 Door closing: 2 ± 0 Departure delay: 0 ± 0

Agents profile: Agents (15292) Handicapped: 74 ± 0 % Start with travel luggage: Show pending agents: 0 ± 0

Agents: Append agents to plan Add Delete Insert Update Default Build

Parameter

agents_00

Id	Agents	Level	Start	Waypoint	Times	Timec	Tdel	Tdep	Group	Wtyp	Profile	Darr	Ddep	Tvar	Tret	Hca
1	129 hole	0	Bus Terminal (Mainlevel)	Baggage (Mainlevel)	25200	25500	45	60	1	2	2	2	0	0	0	24
2	128 hole	0	Bus Terminal (Mainlevel)	Kiosk (Mainlevel)	25200	25500	15	30	1	0	4	2	2	0	0	24
3	129 hole	0	Bus Terminal (Mainlevel)	Metro S12 Lausanne (Platform South)	25200	25500	25770	1	1	4	2	2	0	0	0	24
4	220 hole	0	Bus Terminal (Mainlevel)	Baggage (Mainlevel)	25200	25500	45	60	2	2	4	2	2	0	0	24
5	220 hole	0	Bus Terminal (Mainlevel)	Metro S12 Lausanne (Platform North)	25200	25500	0	25200	2	1	4	2	2	0	0	24
6	220 hole	0	City Entrance East (Mainlevel)	Bistro (Mainlevel)	25200	25500	45	60	3	0	4	2	2	0	0	24
7	220 hole	0	City Entrance East (Mainlevel)	Metro S12 Lausanne (Platform South)	25200	25500	0	25200	2	1	4	2	2	0	0	24
8	140 hole	0	City Entrance West (Mainlevel)	Kiosk (Mainlevel)	25200	25500	45	60	4	0	4	2	2	0	0	24
9	140 hole	0	City Entrance West (Mainlevel)	Metro S12 Lausanne (Platform South)	25200	25500	25680	25770	3	1	4	2	2	0	0	24

9 / 9 modified C:\ProgramData\SimWalk 4.0\Projects\Railway Station\agents_00.swa

New: Press the [O/D] button if you want to display the agents plan as an Origins / Destinations matrix.

Parameter


agents_00

O/D-Matrix

Origins \ Destinations (on level)	VillageNE (Groundfloor)	VillageSE (Groundfloor)	VillageSW (Groundfloor)	S11_Baden (P6)	S7_Zuerich (P5)
VillageNE (Groundfloor)		50	50		30
VillageSE (Groundfloor)			150		15
S11_Baden (P6)	30	80	70		
S7_Zuerich (P5)		60	80		

0 / 4 read only C:\ProgramData\SimWalk 4.0\Projects\Demo_TrainStation\agents_00.swa


49 To insert a waypoint in an existing agents group, click into a row of the Parameter table and [Insert] a new row below. The upper row will be duplicated and can then be edited. After the selected data has changed, [Update] the Parameter table. You may also [Delete] the selected data from the Parameter table.




Parameter							
agents_00							
Id	Agents	Level	Start	Waypoint	Tmin	Tmax	...
1	128 hide	0	Bus Terminal (MainLevel)	Baggage (MainLevel)	25200	25500	4
2	128 hide	0	Bus Terminal (MainLevel)	Kiosk (MainLevel)	25200	25500	1
3	128 hide	0	Bus Terminal (MainLevel)	Metro S12 Lausanne (Platform South)	25200	25500	2
4	220 hide	0	Bus Terminal (MainLevel)	Baggage (MainLevel)	25200	25500	4
5	220 hide	0	Bus Terminal (MainLevel)	Metro S12 Rennens (Platform North)	25200	25500	0
6	220 hide	0	City Entrance East (MainLevel)	Bistro (MainLevel)	25200	25500	4
7	220 hide	0	City Entrance East (MainLevel)	Metro S12 Lausanne (Platform South)	25200	25500	0
8	140 hide	0	City Entrance West (MainLevel)	Kiosk (MainLevel)	25200	25500	4
9	140 hide	0	City Entrance West (MainLevel)	Metro S12 Lausanne (Platform South)	25200	25500	2

50 If external timetable(s) are available, you can use it to import waypoints and schedules in an easy way. Just press the [Start] or [Exit] timetable button. The default timetable (defined in the Configuration) is loaded into the timetable window. Double-click into a row to import the corresponding schedule.


Note: Of course the waypoints in your timetable must be available in the start and/or exit points list, otherwise the message 'Unknown start/exit point' appears.



51 Press the [Timetable] button to open the timetable menu. Here you can select the desired timetable, load or import a new timetable. To load timetable(s), select the appropriate SimWalk Timetable (.swt) file.



52 You also can import timetables in text (.txt or .csv) or Excel (.xls/x) format.



53 Repeat point 51 if you want to open an external timetable in the XML format, e.g. from a third-party program like OpenTrack.



54 After selecting the XML file, the Timetable Converter opens. Select the appertaining timetable definition and press the button to [Convert] the data. You may also define and save your own timetable format(s) so long as the data is provided in the XML format.

SimWalk - Timetable Converter

#	Train Id	Train type	Station Id	Station type	Waypoint	Start time	End time
1	18020	planned	STET	stop	STET	07:15:20	07:15:20
2	18020	planned	ZSTH	stop	ZSTH	07:19:00	07:21:00
3	18020	planned	ZMUS	stop	ZMUS	07:24:00	07:29:00
4	18021	planned	ZMUS	stop	ZMUS	07:04:00	07:05:20
5	18021	planned	ZSTH	stop	ZSTH	07:09:00	07:10:30
6	18021	planned	STET	pass	STET	07:14:00	07:14:00

Train elements: Start tag: train, End tag: train, trainID: 18020, type: planned. Station elements: Start tag: entry, End tag: entry, posID: 18020, type: pass. Import elements: Waypoint: posID, Start time: arrival, End time: departure, Min. stop time: . Timetable definition: RailML Vers. 1.1. Special characters: ; - : . Stop: stop. Start timetable conversion.


Convert

Cancel Accept

Ready... UTF-8 C:\ProgramData\SimWalk 4.0\Projects\Railway Station\Timetable.RailML.xml

Hint: Timetables are defined in the 'defaults.swc' file.

55 Repeat point 51 to select the desired timetable.



56 After entering all agent routes and saving the Parameter table, you are ready to [Build] the agents plan.

The Agents dialog box displays the following settings:

- First step: Start point: Bus Terminal (MainLevel), Start time: 07:00:00, End of range: 07:05:00, Door opening: 2 s, Arrival variation: 0 s.
- Next step(s): Waiting point: Baggage (MainLevel), Waiting time: 45 s, End of range: 60 s, Travel baggage check-in: checked, Travel baggage reclaim: unchecked.
- Last step: Exit point: (empty), Arrival time: 00:00:00, Departure time: 00:00:00, Door closing: 2 s, Departure delay: 0 s.
- Agents profile: Agents (15292), Handicapped: 74 %, Start with travel bagname: checked, Show pending agent: unchecked.

The 'Build' button is highlighted with a tooltip: "Build a new agents plan".

The Parameter table (agents_00) shows the following data:

Id	Agents	Level	Start		Waypoint		Tmin	Tmax	Tdel	Tdep	Group	Wtyp
			Point	Point	Point	Point						
1	128 hide	0	Bus Terminal (MainLevel)	Baggage (MainLevel)	25200	25500	45	60	1	1	2	
2	128 hide	0	Bus Terminal (MainLevel)	Kiosk (MainLevel)	25200	25500	15	30	1	1	0	
3	128 hide	0	Bus Terminal (MainLevel)	Metro S12 Lausanne (Platform South)	25200	25500	25680	25770	1	1		
4	220 hide	0	Bus Terminal (MainLevel)	Baggage (MainLevel)	25200	25500	45	60	2	2	2	
5	220 hide	0	Bus Terminal (MainLevel)	Metro S12 Rennens (Platform North)	25200	25500	0	25200	2	1		
6	220 hide	0	City Entrance East (MainLevel)	Bistro (MainLevel)	25200	25500	45	60	3	0		
7	220 hide	0	City Entrance East (MainLevel)	Metro S12 Lausanne (Platform South)	25200	25500	0	25200	3	1		
8	140 hide	0	City Entrance West (MainLevel)	Kiosk (MainLevel)	25200	25500	45	60	4	0		
9	140 hide	0	City Entrance West (MainLevel)	Metro S12 Lausanne (Platform South)	25200	25500	25680	25770	5	1		

The status bar at the bottom shows: 1 / 9 and C:\ProgramData\SimWalk 4.0\Projects\Railway Station\agents_00.swa

57 If the plan building process was successful, the generated plan file ('plan_00.swt') is shown in the parameter table. You are now ready to start a simulation run (see point 64 below).

Parameter

plan_00

Id	Starttime	X	Y	Level	Speed	Breadth	Height	Person	Show	Exit	Type	Priority	Profile	Extend	Handicap	Style	Age	Gender
0	15	41.99	57.33	0	1.49	0.49	1.77	133	2	2	536370912	0	Traveler	0.00	none	Sportive	33	Female
1	155	42.49	64.40	0	1.92	0.56	1.88	26	2	2	536377290	0	Traveler	0.08	Dog	Sportive	26	male
2	41	42.61	59.79	0	0.90	0.36	1.75	131	2	2	67132960	0	Traveler	0.04	Handcart	Casual	31	Female
3	267	41.21	54.43	0	2.02	0.49	1.86	23	2	2	536377290	0	Traveler	0.08	Dog	Sportive	23	male
4	275	42.01	64.17	0	1.66	0.37	1.79	132	2	2	67309888	0	Traveler	0.08	Dog	Casual	32	Female
5	155	40.77	57.44	0	1.51	0.52	1.84	36	2	2	536370912	0	Traveler	0.00	none	Sportive	36	male
6	280	43.01	61.33	0	1.15	0.37	1.74	132	2	2	68157440	0	Traveler	0.20	Suitcase / Trunk	Casual	32	female
7	73	41.69	61.27	0	1.66	0.44	2.01	31	2	2	536371308	0	Traveler	0.40	Couple	Sportive	31	male
8	137	41.94	59.93	0	1.52	0.49	1.93	26	2	2	67309992	0	Traveler	0.26	Child	Casual	26	male

17708 read only C:\ProgramData\SimWalk 4.0\Projects\Railway Station\plan_00.swt

Hint: The number of plan files is limited to 100 ('plan_00.swt' to 'plan_99.swt').

58 If you want to rebuild an existing agents plan, you can select the appropriate template file (.swa) in the Parameter table (like 'agents_01') and then press [Build] button.

Parameter

agents_01

plan_00

agents_00


agents_01

	Waypoint	Tmin	Tmax	Tdel	Tdep	Group	Wtyp
Table empty							

C:\ProgramData\SimWalk 4.0\Projects\Demo_TrainStation\agents_01.swa


Hint: The number of template files is limited to 100 ('agents_00.swa' to 'agents_99.swa').

59 Use the export function if you want to save your agents plan as an Excel or text file.




New: Save as XML (UTF-8) or XLSX for vast amount of data. Excel before 2007 (XLS) is limited to 65'536 rows - extended XLSX format allows export of over a million rows.


60 Use the import function to load an Excel or text file into the agents plan.




61 Press the [Profiles] button (or select the Profiles tool menu item) to modify an existing profile or create a new one.



62 The Agent profiles window opens and you can select an Agents profile to modify. To create a new profile, select first Agents activity and region to set default parameters. Adjust each parameter like Agents walking speed range or body breadth as you like. Press the [Handicaps] button to modify pedestrian accessories and other settings which affect the walking speed, resulting in a restriction of mobility.




63 After modifications press the [Profile name] button to rename the profile. At last press the <Enter> key to complete the input. Finally [Save] the agents profile. Optionally you can [Select an icon] for your profile. The same applies to handicaps (see figure above).



Hint: Profiles, activities, regions, handicaps, styles, and utilizations are defined in the 'defaults.swc' file.

64 If the agents plan was built successfully, you are able to start your first simulation run. Using 'Select a task' menu, choose task 'Run a new simulation' and follow the steps in chapter 1.



Note: After modifying any start area, vehicle, formation, or profile, you have to rebuild the agents plan before starting a new simulation run.